

Tastatura za Lenovo ThinkPad Yoga L380 20M7 20M8 osvetljenje

Šifra: hobo-74Z

Kategorija proizvoda: Tastaure za Lenovo

Proizvođač: Lenovo

Cena: **3.190,00** rsd.



Odgovara za model: 20M7001BPG, 20M7001DPG, 20M7001EPG, 20M7001FPG, 20M7001GPG, 20M7001HPG, 20M7001JPG, 20M70027PG, 20M70028PG, 20M7002HPG, 20M7002JPG, 20M70037PG, 20M70038PG, 20M70039PG, 20M7003APG, 20M7003DPG, 20M7003EPG, 20M7003FPG, 20M7003GPG, 20M80015PG, 20M80017PG, 20M80018PG, 20M80019PG, 20M8001LPG, 20M8001QPG

Part Number: 01YN321, 01YN361, 01YN401, 01YN441, 01YP261, 01YP301, 01YP341, 01YP381, 01YP421, 01YP461, 01YP501, 01YP541, 06F00B2, 2B-BBE15W602, 559000G, 81M05KP, 82S0056, 85J001N, 89N0010, 8AK000A, 94D0007, 95N000Y, CM85, CMFBL-85PO, CMFNBL-85PO, FU53712, FU5371BL1, FU5371BL2, SN20P32815, SN20P32891, SN20P33051, SN20P33131, SN20P33211, SN20P33291, SN20P33291AB, SN20P33371, SN20P34823, SN20P34943, SN20P34983, SN5371, V170820CK1 PO, V170820DK1 PO

Compatible Models: Attention to the Function Keys F9->F11