

Tastatura Acer Packard Bell EasyNote EN TS44HR
EN TS44SB EN TS45HR EN TS45SB

Šifra: Hobo-3Z

Kategorija proizvoda: Tastature za Acer

Proizvođač: Packard Bell

Cena: **1.399,00** rsd.

Part Number: KBI170A388, KBI170A404, NK.I1713.061, NK.I1713.065, NK.I1713.09V, NKI1713060, PK130042B17, V121702GK3, V121702GK3 PO
Part Number: 6B.MZTN7.019, 6B.MZ8N1.021, 9Z.N9MBC.106, 9Z.N9MBC.A06, 9Z.N9MSC.C06, KB.I170A.385, KB.I170A.387, KB.I170A.388, KB.I170A.391, KB.I170A.392, KB.I170A.393, KB.I170A.395, KB.I170A.399, KB.I170A.401, KB.I170A.403, KB.I170A.404, KB.I170A.406, KB.I170A.409, KBI170A385, KBI170A387, KBI170A391, KBI170A392, KBI170A393, KBI170A395, KBI170A399, KBI170A401, KBI170A403, KBI170A406, KBI170A409, NK.I1713.034, NK.I1713.05F, NK.I1713.05H, NK.I1713.05J, NK.I1713.05M, NK.I1713.05N, NK.I1713.05P, NK.I1713.05Q, NK.I1713.05R, NK.I1713.05S, NK.I1713.05V, NK.I1713.05X, NK.I1713.05Z, NK.I1713.060, NK.I1713.062, NK.I1713.064, NK.I1713.09N, NK.I1713.09S, NK.I1717.040, NK.I1717.04H, NK.I171S.005, NK.I171S.007, NK.I171S.008, NK.I171S.00B, NK.I171S.00C, NK.I171S.00D, NK.I171S.00E, NK.I171S.00F, NK.I171S.00G, NK.I171S.00K, NK.I171S.00M, NK.I171S.00P, NK.I171S.00Q, NK.I171S.00R, NK.I171S.00S, NK.I171S.00U, NK.I171S.00V, NKI1713034, NKI171305F, NKI171305H, NKI171305J, NKI171305M, NKI171305N, NKI171305P, NKI171305Q, NKI171305R, NKI171305S, NKI171305V, NKI171305X, NKI171305Z, NKI1713061, NKI1713062, NKI1713064, NKI1713065, NKI171309N, NKI171309S, NKI171309V, NKI1717040, NKI171704H, NKI171S005, NKI171S007, NKI171S008, NKI171S00B, NKI171S00C, NKI171S00D, NKI171S00E, NKI171S00F, NKI171S00G, NKI171S00K, NKI171S00M, NKI171S00P, NKI171S00Q, NKI171S00R, NKI171S00S, NKI171S00U, NKI171S00V, NSK-R6ABC 06, NSK-R6CSC 06, PK130N43A17, PK130VR1A17, R61BC 06, NSK-R61BW